



MANUAL DE OPERACIÓN AUDIOVISUAL BÁSICO



Tocar pantalla para abrir sesión

MÁSCARA INICIO DE SESIÓN (PANTALLA TÁCTIL DE CONTROL)



Tocar ícono Presentación

MÁSCARA DE PRESENTACIÓN (PANTALLA TÁCTIL DE CONTROL)



Modo Videoconferencia

- Tocar el ícono
- En la mesa conectar el cable "Y" a su Notebook.
(USB-C o USB-A)

- Si elige Clickshare:
Conectar botón USB
a su Notebook

- Si elige HDMI:
Conectar su Notebook con el
cable en la entrada de la mesa

MANUAL DE OPERACIÓN AUDIOVISUAL BÁSICO

CONEXIÓN CABLE “Y” EN LA MESA (PARA MODO VIDEOCONFERENCIA)



Si el equipo es externo, deberá instalar el driver señalado en este link

<https://www.synaptics.com/products/displaylink-graphics/downloads>

MANUAL DE OPERACIÓN AUDIOVISUAL BÁSICO

Ingresar a Plataforma Video Conferencia

Predeterminar por única vez el audio y cámara

The screenshot displays the configuration interface for a video conference. It is divided into two main sections: 'Configuración' (Configuration) on the left and 'Cámara' (Camera) on the right. The 'Configuración' section has a sidebar with 'Audio' selected. The 'Audio' settings are shown in a modal window with the following elements:

- Micrófono:** A dropdown menu set to 'Predeterminado - Varios micrófonos ...' is highlighted with a red box labeled 'Paso 1'.
- Cancelación de ruido:** A toggle switch is turned on.
- Altavoces:** A dropdown menu is open, showing several options. The option 'Predeterminado - Teléfono con altavoz co...' is highlighted with a red box labeled 'Paso 2'.
- Probar:** A speaker icon and the word 'Probar' are visible.

The 'Cámara' section on the right has a modal window with the following elements:

- Cámara:** A dropdown menu is set to 'Logi Rally Camera (046d:0881)', which is highlighted with a red box labeled 'Paso 3'.
- Resolución de envío (máxima):** A dropdown menu set to 'Automático'.
- Resolución de recepción (máxima):** A dropdown menu set to 'Automático'.

Presionar probar audio para comprobar que los parlantes estén funcionando correctamente.

This close-up shows the 'Altavoces' section of the configuration window. The dropdown menu is set to 'Predeterminado - Teléfono con altavaz...'. A red box labeled 'Paso 4' points to the 'Probar' button, which features a speaker icon.

MANUAL DE OPERACIÓN AUDIOVISUAL BÁSICO

Ingresar a Plataforma Video Conferencia

Predeterminar por única vez el audio y cámara

Otras Plataformas de Video Conferencia Zoom, Microsoft Teams, etc

The image displays two screenshots of a video conferencing interface, likely Microsoft Teams, illustrating the steps to select audio and camera settings.

Left Screenshot: Shows the 'Select a Microphone' and 'Select a Speaker' menus. The selected microphone is 'Teléfono con altavoz con cancelación de eco (4- Logi Rally Audio)'. The selected speaker is also 'Teléfono con altavoz con cancelación de eco (4- Logi Rally Audio)'. The 'Mute' button is highlighted with a red box and a red arrow pointing to it.

Right Screenshot: Shows the 'Select a Camera (Alt+N to switch)' menu. The selected camera is 'Logi Rally Camera'. The 'Stop Video' button is highlighted with a red box and a red arrow pointing to it.

Audio Settings (Left Screenshot):

- Select a Microphone:**
 - Varios micrófonos (Realtek High Definition Audio)
 - ✓ Teléfono con altavoz con cancelación de eco (4- Logi Rally Audio)
 - Same as system
- Select a Speaker:**
 - Altavoces (4- Logi Swytch Audio)
 - Altavoz/Auricular (Realtek High Definition Audio)
 - ✓ Teléfono con altavoz con cancelación de eco (4- Logi Rally Audio)
 - Same as System
 - Test Speaker & Microphone...
 - Leave Computer Audio
 - Audio Settings...

Camera Settings (Right Screenshot):

- Select a Camera (Alt+N to switch):**
 - ✓ Logi Rally Camera
 - Integrated Camera
 - Choose Virtual Background...
 - Choose Video Filter...
 - Video Settings...

Bottom Bar (Left Screenshot):

- Mute (highlighted with a red box and a red arrow)
- Stop Video
- Security
- Participa

Bottom Bar (Right Screenshot):

- Stop Video (highlighted with a red box and a red arrow)
- Security